

NoMorePly Solid Bed Adhesive

PRODUCT DESCRIPTION

NoMorePly® Solid Bed Adhesive is a high strength, single component advanced silane polymer adhesive.

PRODUCT USES

Used for bonding **NoMorePly** fibre-cement boards, onto the type of underfloor heating system which utilises water pipes set into grooved boards or insulation panels.

PACKAGING

Packaged in a sealed bag within a 17 kg plastic bucket.

TECHNICAL INFORMATION

COMPOSITION

NoMorePly® Solid Bed Adhesive is formulated from advanced silane polymer technology.

CHARACTERISTICS

OPEN TIME

Approximately 20 minutes

USAGE GUIDELINES

PREPARATION

- All phases of installation should comply with BS 8201, BS 8203, CP 102 and /or other local installation standards and codes of practice.
- Ensure the subfloor is load-bearing, clean, sound and dry and free from contaminants that may hinder adhesion, this includes, paint, varnish, polish, old adhesive residues and plaster spots.
- Existing wooden subfloor must have an intact base DPM.
- Any voids in the grooved panels should be filled with a suitable levelling compound, unless they are no wider than the heating pipes and do not line up with the edges of the NoMorePly boards.

Please note : Always fix the boards/panels down to the substrate before laying NoMorePly.

If it is not possible to fix the boards/panels down to the substrate, the floor is essentially 'floating' and therefore not considered suitable for tiling over. 9mm NoMorePly has been proven to give a sound base for tiling over floating floors, but this is not covered by the guarantee.

**QUICK
& EASY**



**THIN
PROFILE**



**STRONGER
BUILD**



**WATER
RESISTANT**



**NON
COMBUSTIBLE**



**LIFETIME
GUARANTEE**





NoMorePly Solid Bed Adhesive

APPLICATION

- On a smooth surface, spread evenly with a 3mm notch trowel
- For rough textured surface, a deeper notched trowel may be required. This will adversely affect the coverage rate of the adhesive.
- Spread the adhesive with a sweeping motion at a 60° angle and place the NoMorePly sheets onto the adhesive while it is still wet.
- Press or gently tap the NoMorePly into the adhesive to ensure good overall contact. Where necessary use heavy objects to hold the NoMorePly in place during curing time.
- Using a flat trowel, lap a small amount of adhesive up the edge of each NoMorePly board and butt the next board tightly against it (this joint-reinforcement is essential to prevent movement).
- The floor will then be suitable to take foot traffic 6 to 8 hours after application. It should then be left 24 hours before laying tiles or floorcoverings.

COVERAGE RATE

Using a 3mm notched trowel the coverage is approx. 0.8 - 1.2 kg/m² (approx. 17 sqm per tub).

CLEANING

Use water immediately after use.

STORAGE

Store in dry conditions between +5°C and +25°C.

SHELF LIFE

12 months when stored as recommended in original unopened packaging.

HEALTH AND SAFETY

Product Health and Safety Data Sheets must be read and understood before use.

THIS INFORMATION IS GIVEN TO THE BEST OF OUR KNOWLEDGE BUT WITHOUT LIABILITY

